


Instructions manual

A1133 ASTERIX FIREPIT & A1133-L OBELIX FIREPIT



WARNING:FOR OUTDOOR USE ONLY

Retain these instructions for future reference

Before using this firepit, make sure you have read, understand and are following all information provided in the following important instructions. Failure to follow can cause death, serious injury or property damage. Improper installation, adjustment, alteration or maintenance can cause injury or property damage.

Important safeguards

- 1, This firepit is for outdoor use only and shall not be used in a building, garage or any other enclosed area. Toxic carbon monoxide fumes can accumulate and cause asphyxiation.
- 2, This firepit is not for commercial use.
- 3, This firepit should only be used by adults and all children and pets should be kept at a safe distance.
- 4, Do not use petrol, white spirit, lighter fluid, alcohol or other similar chemicals to light a fire as a rapid increase in temperature could damage the firepit. This firepit is only suitable for use with charcoal, untreated wood or dry logs. Do not use coal.
- 5, Do not use this firepit until it is completely assembled and all parts are securely fastened and tightened.
- 6, Do not use the product on decking or any other flammable surfaces such as dry grass, wood chips, leaves, wood floor.
- 7, Always empty this firepit after use. Leave a thin layer of ash to protect the bottom. Do not remove ashes or charcoal until they are completely and fully extinguished.
- 8, Do not touch the firepit until it is completely cooled unless you are wearing heat resistant gloves as it is hot when in use.
- 9, Do not handle or move the firepit when in use as it is hot.
- 10, Do not attempt to store the firepit until all ashes and charcoals are completely extinguished.
- 11, Always use a safety tool and heat resistant gloves when adding or moving fuel.
- 12, Always use a safety tool and heat resistant gloves to move the grill and mesh cover during use because the firepit will become very hot.
- 13, Do not leave a burning fire unattended.
- 14, Fire hazard-Hot embers may emit while in use.

- 15, Do not overload the firepit with fuel. Two small logs, 1600g, is sufficient. Do not add additional fuel until the fire burns down.
- 16, Do not burn fuel directly on the firebowl base. Do burn on the log grate or ash.
- 17, Do keep the fuel away from the wall of the firepit as the high temperature may damage it.
- 18, Avoid breathing smoke from the fire and avoid getting it into your eyes.
- 19, Always thoroughly inspect the firepit before use.
- 20, A slight discoloration of finish may occur after use.

LIGHTING

- 1, Ensure the firepit is positioned on a permanent flat, level, heat resistant, non-flammable surface away from flammable items.
- 2, Make sure there is a small amount of ash in the firebowl bottom.
- 3, Place paper or dry kindling on the log grate or ash in the centre of the firebowl bottom.
- 4, Place fuel on the paper or dry kindling.
- 5, Light the paper or dry kindling to start a fire.

TENDING THE FIRE

- 1, Add fuel to the firepit to increase the heat slowly when embers glow. Do not overload with fuel, only two or three small logs, like 1600g, or 500g of charcoal, is sufficient.
- 2, When shifting logs, use a safety tool to allow for additional airflow.

EXTINGUISHING

To extinguish the firepit, stop adding fuel and allow fire to die or douse with sand. Do not use water as this may damage the firepit.

CARE AND INSPECTING

- 1, This firepit should be inspected on a regular base to ensure product safety and longer product life.
- 2, The firepit should be cleaned after use to ensure longer product life. Do not use oven cleaner or abrasive cleaner as they will damage this product.
- 3, When not in use, cover the firepit once completely cooled with a cover to help protect it from bad weather.
- 4, Store this firepit in a dry location to maximise product life.
- 5, As the firepit is made from steel, the surface will age and develop surface rust as soon as it is placed outside and after use. This is to be expected, but it does not affect use and is not a product fault. Please see below instructions on how to refresh the paint finish.

Remove loose paint and rust with a wire brush when needed and re-paint using a high temperature paint, resistant to at least 600°C.

To help reduce surface rust, rub the firepit with an oily rag after each use.

21x29.7cm

PART LIST




1 (1x)



2 (1x)




3 (4x)



4 (1x)



5 (1x)



6 (1x)




7 (3x)



8 (3x)

ASSEMBLY



STEP 1- Attach the 3x legs (8) to the bottom of the body section (6) using 3x wing bolts (7) into the pre-threaded bracket at the top .

STEP 2- Attach the flue cap (2) to the flue section (4) using 4x bolts and nuts (3) .

STEP 3- Place the assembled flue cap and flue section (4) onto the assembled body section (6) .

STEP 4- Insert the log grate (5) into the body section (6) .

Your product is now ready to use, but please ensure you have read these instructions thoroughly prior to use.